

# P O T T E R Y B A R N

## Mervelle Floral Hook Mounting instructions

### Tools Required

- Phillips Head Screwdriver
- Pencil

### Hardware Included:

- A · 2 Drywall screws
- B · 2 Metal drywall Anchors

Note: For safe mounting, it is essential to use the proper hardware for your wall type. Be sure to consult your local hardware store to determine the hardware needed for your wall type (plaster, drywall, concrete, etc.). Mount to wood studs whenever possible. Enclosed hardware is meant for dry wall/wood stud mount only. Two people are recommended for safety and ease mounting.

### Mounting Instructions:

#### Step 1

Determine the anchor mounting position on wall and mark with a pencil.

#### Step 2

Place anchor onto a Phillips screwdriver.

Position anchor with drill point facing mark on the wall. With slight pressure applied to the anchor, begin turning the screwdriver “drilling” the anchor into the wall.

Important: Do not push the anchor drill point into the wall first and then begin turning the screwdriver as this may snap the drill point off and anchor will no longer function properly.

#### Step 3

Continue to turn the anchor using a slight inward pressure.  
Turn the anchor until the flange is flush with the wall surface.

#### Step 4

Place the Mervelle Floral Hook over the Anchor and tighten the Drywall screw with the help of a screwdriver

