

P O T T E R Y B A R N

HARLOW MIRROR Mounting Instructions

This mirror includes two D rings on its rear surface for wall mounting.

Tools needed: Level, Tape Measure, Stud Finder, Phillips Screwdriver and a Pencil.

Hardware Included: (2) Screws and (2) Anchors.

Use a tape measure to measure the distance between the D rings (measure from the center of each). This measurement is "Measurement A."

This mounting hardware is meant for dry wall/stud mounting only. If walls are concrete, brick or plaster, please consult your local hardware store for assistance.

- 1) With the help of others, hold the mirror against the wall in a desired mounting position so that the rear faces away from the wall. Use a level to ensure that the mirror is being held level and then use a pencil to mark the wall on each side of the mirror adjacent to and in line with the key hole. Carefully set the mirror aside.
- 2) Use a straightedge and a pencil to connect the two marks with a pencil line. Then use the tape measure and the pencil to make two "anchor marks" centered along this line that are spaced a distance equal to "Measurement A." The hardware will be installed at these two anchor marks.
- 3) The anchors provided with this mirror cannot penetrate wood studs. Therefore we have to find out if either of the two marks of Step (2) happens to align with a wall stud. Use a stud-finder to determine this. If a mark does align, use the screwdriver to install only a screw at this mark - do not use an anchor. Drive the screw directly into the wall and stud until the screw head resides about 3/8" inch from the wall.
- 4) For marks that do not align with a stud, use a Phillips screwdriver to install an anchor into the wall at these marks. Firmly push the anchor into the wall as you rotate it clockwise. The anchor will drive itself into the wall like a screw. Continue rotating until the wide flange of the anchor is even with the wall.
- 5) Use the screwdriver to secure a provided screw into each installed anchor. Rotate each screw clockwise until the screw heads are about 3/8" from the wall.
- 6) With the help of another person, lift the mirror against the wall so that the two key hole align and engage the protruding screw heads.

Care Instructions:

- Dust often with a soft, dry cloth
- Avoid using strong chemical or abrasive cleaners.
- To clean the mirror surfaces, use a household glass cleaner but spray the cleaner onto a clean cloth first and then use the cloth to wipe the mirror surfaces clean - do not spray the cleaner directly onto the mirror surfaces.

Thank you for your Purchase!
Stores | Catalog | www.potterybarn.com
USA 1.800.290.8181