

P O T T E R Y B A R N

general mounting instructions three panel mirror

Note: For safe mounting, it is essential to use the proper hardware for your wall type. Be sure to consult your local hardware store to determine the hardware needed for your wall type (plaster, drywall, concrete, etc.). Mount to wood studs whenever possible. Two people are recommended for safety and ease of mounting.

Hardware Included:

2 Screws
2 Hollow Wall Anchors

Mounting Instructions:

1. Hold the mirror at desired location. With a pencil, mark on wall at the top outside corners of the mirror. (See Illustration A.)
2. Measure the distance from both sides of mirror to the top of each keyhole notch on the back. Mark this measurement down from the first mark on the wall. (See Illustration A.)
3. Measure the distance from both sides of mirror to the center of the keyhole slots. Mark this spacing on the wall, measuring in from the lower pencil marks. These marks indicate the location for the screws. Use a carpenter's level or measure up from the floor at each mark to be sure that cabinet will be level.
4. Using the proper hardware for your wall type, drill holes, if necessary, to insert anchors. Then insert screws into wall leaving approximately $\frac{1}{2}$ " from the wall to the back of the screw head. (See Illustration B.)
5. Mount mirror by fitting the lower hole of keyhole slots over screw heads and sliding mirror down until the top of the keyhole slots rest on the screws. You may need to tighten or loosen screws to allow mirror to fit snugly against the wall.

Care Instructions:

Wipe with a soft, dry cloth only. Avoid cleaners and abrasives as they may damage the finish.

thank you for your purchase