

P O T T E R Y B A R N

Vintage Medicine Cabinet

Mounting Instructions

Note:

This mounting hardware is meant for dry wall/stud mounting only. If walls are concrete, brick or plaster, please consult your local hardware store for assistance.

Professional Installation strongly recommended.

Note: Maximum total weight capacity for this product is 40 pounds in total (18.1 KG), 10 pounds (4.5 KG) per individual shelf & horizontal surface.

Tools Needed:

Tape Measure, Stud Finder, #2 Phillips screwdriver, Pencil

Parts Included:

- (1) Medicine cabinet
- (2) tempered glass
- (4) Metal screws
- (4) Dry Wall anchors (for dry wall only)

For stud mounting the anchors are not required, use only the screws.

Stud Mounting

1. Set medicine cabinet onto the recessed wall.
2. With a Phillips screwdriver (or drill) insert metal screws into the stud clockwise until tight.

Care Instructions:

Wipe with a soft, dry cloth. To protect the finish, do not use household cleaners or abrasives.

