

POTTERY BARN

Clifton Bath Fixtures

Note: For safe mounting, Pottery Barn recommends the following:

- Stud mounting is preferred over dry wall mounting when possible.
- Consult your local hardware store if you have any questions about installing your Accessories.
- Tools needed for installation: Phillips head screwdriver, Measuring Tape, Level & Pencil

Parts Needed for

Towel Ring, Wall Hook, TP Holder, Wall Votive Holder,
Soap & Wash Cloth Holder, Tooth Brush Cup Holder & Wall Vase

- 1 Wall Mount back plate
- 3 Mounting screws
- 3 Dry wall anchors
- 2 Allen screws
- 1 Ball Head Allen Wrench

Parts Needed for

Towel Rods 18" & 24", Glass Shelf 18" & 24"
& Magazine Rack

- 2 Wall Mount back plates
- 6 Mounting screws
- 6 Dry wall anchors
- 4 Allen screws
- 1 Ball Head Allen Wrench
- 2 Set Screws (for glass shelf)

Tools Needed for Installation

- Philip head screwdriver
- Measuring tape
- Level
- Pencil

Mounting Instructions

Note: Keep original bracket and back plate together to ensure proper fit.

Stud Mounting Instructions

1. Locate interior wood studs through wall. Place the back plate over the wood stud at the desired height. The screw holes should be placed in an inverted Y configuration – one screw hole directly at the top and two screw holes in the lower right and left hand regions. Mark the location of back plate holes on the wall with a pencil.
2. Use a measuring tape and a level to determine the proper placement of the remaining back plate.
3. Align the back plate with the pencil markings; making sure the smooth surface of the plate is against the wall. Insert the metal screws through the back plate holes. Using a screwdriver, turn the screws clockwise until the plate is secured snugly to the wall. Metal screws will not be flush to the back plate.
4. Place the mounting bracket over the back plate
5. Using the Ball Head Wrench, tighten each screw a little at a time until the bracket is securely attached to back plate. Avoid over tightening as over tightening may cause damage to the back plate. Screws should not be completely flush to the side of the bracket, but should stick out slightly.

Dry Wall Mounting Instructions

1. Placing the back plate at the desired height. The screw holes should be placed in a Y configuration – one screw hole directly at the bottom and two screw holes in the upper right and left hand regions. Mark the location of back plate holes on the wall with a pencil.
2. Use a measuring tape and a level to determine the proper placement of the remaining back plate.
3. Using a screwdriver, screw the dry wall anchors directly into the wall at the pencil marks. Do not force the screws as they are designed to bore a hole into the wall without much pressure.
4. Align the back plate with the anchor screws, making sure the smooth surface of the plate is facing the wall. Insert the metal screws through the back plate holes and place into the wall anchor holes. Using a screw driver, turn the screws clockwise until the plate is secured snugly to the wall. Metal screws will not be flush to the back plate.
5. Place the bracket over the back plate.
6. Using the Ball Head Wrench, tighten each screw a little at a time until bracket is securely attached to back plate. Avoid over tightening as over tightening may cause damage to the back plate. Screws should not be completely flush to the side of the bracket, but should stick out slightly.

Care Instructions: Wipe with a soft, dry or slightly damp cloth. To protect the finish, do not apply household cleaners or abrasives.

