

P O T T E R Y B A R N

Jocelyn Hand Carved Mirror Mounting Instructions

Note: For safe mounting, Pottery Barn recommends the following:

- Stud mounting is preferred over dry wall mounting when possible.
- Consult your local hardware store if you have any questions about installing this product.
- The Mirror can be hung both vertically or horizontally.

Parts included:

1- Jocelyn hand carved Mirror

Hardware Included:

- (2) Anchors
- (2) Screws

Tools required for installation:

- Phillips-head screwdriver

Wood Stud Mounting:

1. Mark the location on the wall.
2. Using a Phillips-head screwdriver, drive the screws into the wall at the location. The screws should not be flush to the wall. Leave a gap of about 1/8" between the head of screw and the wall.
3. Hang the Jocelyn hand carved Mirror on the screw heads. If it does not fit properly, you may need to adjust the gap between the head of screw and the wall and hang again.

Dry Wall Mounting:

1. Mark the location on the wall.
2. Using a Phillips-head screwdriver, drive the toggle anchors directly into the wall at the location. Do not force the toggle anchors as they are designed to bore a hole into the wall without much pressure.
3. Using a Phillips-head screwdriver, drive the screws into the toggle anchors. The screws should not be flush to the wall. Leave a gap of 1/8" between the head of screw and the wall.
4. Hang the Jocelyn hand carved Mirror on the screw heads. If it does not fit properly, you may need to adjust the gap between the head of screw and the wall, and hang again.

Care and Instruction:

- Wipe with a soft, dry cloth.
- To protect the finish, do not apply household cleaners or abrasives.

Thank you for your purchase