

P O T T E R Y B A R N

Cast Iron Hanger Hook mounting instructions

Note: This hardware is meant for dry wall/stud mounting only. If walls are concrete, brick or plaster, please consult your local hardware store for assistance.

Maximum weight capacity: 15 lbs

Parts and Hardware Included:

- 2pcs Toggle anchors
- 2pcs Toggle screws
- 1pc Cast Iron Hanger Hook

Mounting Instructions:

1. Hold the Cast Iron Hanger Hook at desired location. With a pencil, mark on the wall the screw hole location. These marks will be used to determine the location of your mounting hardware.
2. Remove from wall. Use a carpenter's level or measure up from the floor at each mark to ensure the Cast Iron Hanger Hook will be level.
3. Use a Phillips screwdriver to insert the toggle anchors. Do not "push" or drive the anchors into the wall, it is designed to bore into the wall like a drill bit. Slowly turn the anchors clockwise while applying pressure until the flange just touches the wall. Keep turning clockwise until one of the arrows on the flange is pointing to the 12 o'clock position.
4. Insert the screws into the toggle anchor separately turning clockwise. At this point, you will feel a slight resistance. This is the point where the toggle screw is engaging the pivoting portion of the anchor. Keep turning screw clockwise until the screw head touches the flange. Tighten the screw until it becomes difficult to turn. At this point the internal pivot will have engaged the backside of the dry wall. Simply grab the screw head and pull it out.
5. Align the Cast Iron Hanger Hook on the wall over the anchors, insert the screws with Phillips screwdriver until tight (caution do not over tighten the screws).

Care Instructions:

Wipe with a soft, dry cloth. To protect the finish, do not use household cleaners or abrasives.

Thank you for your purchase

