

P O T T E R Y B A R N

Feather Shadowbox Wall Art

Mounting Instructions

Note: The hardware included with this item is meant for drywall or stud mounting only. If your wall is made from other material such as concrete, brick or plaster, please consult your local hardware store for assistance in selecting the appropriate hardware.

Tools Required: Pencil, Philips Screwdriver,
Tape measure, Stud-Finder, Level

**DO NOT USE A CABLE TO HANG THIS PRODUCT.
THE D-RINGS MUST HANG DIRECTLY FROM THE
SECURED SCREWS!**

Hardware Included: (2) Anchors
(2) Screws

This item includes one pair of D-rings on the back for supporting the item against a wall. Before you get started, use a tape measure to measure the exact distance between the two D-rings (measure from center to center of each D-ring). This measurement is "**Distance A**".

MOUNTING INSTRUCTIONS:

- 1) With the help of another person, hold the item against a wall at a desired mounting location so that the back of the item faces towards you and you can see the D-rings. Use a level to ensure the item is being held level and then, using a pencil, mark the wall on each side of the item adjacent to each D-ring so that the two pencil marks and the two D-rings are all horizontally aligning. Set the item aside.
- 2) Connect the two marks of Step #1 with a light pencil line and then use a level to make sure that line is level (adjust if necessary).
- 3) Use the pencil and the tape measure to make two "insertion marks" centered along the line of Step #2 that are spaced apart a distance equal to "**Distance A**". These are the insertion points for the mounting hardware.
- 4) The provided anchors cannot penetrate wood studs. Therefore we have to find out if either insertion mark of step #3 happens to align with a wood stud (use a stud-finder to determine this). If either does, do not use the anchor at that mark – use a screw only. In this instance, use a screwdriver to secure the screw directly into the wall at that mark. Rotate clockwise until the screw head resides about 3/8 inch from the wall.
- 5) For insertion marks that do not align with a stud, first install an anchor into the wall. To do this, use a Phillips screwdriver to engage an anchor and then position the anchor tip against the wall at one of the marks. Rotate the anchor clockwise as you firmly push it into the wall. The anchor will drive itself into the wall like a large screw. Continue rotating until the anchor's head becomes even with the wall surface. Do not over-tighten.
- 6) Now secure a screw into each installed anchor and use a screwdriver to rotate the screw clockwise until the screw head is about 3/8 inch from the wall.
- 7) Mount the item to the wall by engaging the D-rings with the protruding screw heads and then lower the item until the screws support its full weight.

Care Instructions: To clean: wipe with a soft, dry cloth.
Do not use abrasive or strong chemical household cleaners.

Thank you for your purchase!
Stores | Catalog | www.potterybarn.com