

P O T T E R Y B A R N

eleanor frameless mirror rectangle

Note:

This mounting hardware is meant for dry wall / stud mounting only. If walls are concrete, brick or plaster, please consult your local hardware store for assistance. For safety and ease of mounting, installation is recommended using two people.

Tools needed

Level, Tape Measure, Stud Finder, #2 Phillips screwdriver, Pencil

Parts Included:

- (1) Template
- (2) Metal Screws
- (2) Dry Wall Anchors (for dry wall only)
- *Note: For stud mounting the anchors are not required, use only the screws.*

Mounting Instructions:

1. Hold the mounting template at the desired location on the wall (use leveler to ensure the template is level). Using a pencil, mark the wall through the template at center of the upper slot of each keyhole (as pointed to on the template).
- NOTE: These marks on the wall are the insertion points for your mounting hardware.

Dry Wall Mounting

1. Use a Phillips screwdriver to insert the wall anchors. Do not “push” or drive the anchors into the wall, it is designed to bore into the wall like a drill bit. Slowly turn the anchors clockwise while applying pressure until the flange just touches the wall.
2. Insert the metal screw into the wall anchor turning clockwise leaving approximately ½” between the back of the screw head and the wall.
3. Align the d-rings over the screw heads. Slide the mirror down until the tops of the d-rings rest on the screws. Tighten or loosen screws as needed to fit the piece snugly against the wall.

Stud Mounting

1. With a Phillips screwdriver (or drill) insert metal screws into the stud clockwise until tight.
2. Align the d-rings over screw heads. Slide the mirror down until the tops of the d-rings rest on the screws.

Care Instructions

Wipe with a soft, dry cloth only. Avoid cleaners or abrasives as they may damage the finish. To clean mirror, spray a small amount of standard glass cleaner on a lint-free cloth and wipe.

thank for your purchase

stores | catalog | www.potterybarn.com