

# POTTERY BARN

## Florence wall hook

*Note:* For safe mounting, it is essential to use the proper hardware for your wall type. Be sure to consult your local hardware store to determine the hardware needed for your wall type (plaster, drywall, concrete, etc.). Mount to wood studs whenever possible. Note for stud mounting the anchors are not required, use only the screws.

Maximum total weight capacity for this product is 20 pounds (9.1 Kg).

### *Parts Included:*

- 2 Screws
- 2 Drywall anchors
- 1 Mounting plate
- 1 Hex screw
- 1 Allen Wrench
- 1 Wall hook

### *Mounting Instructions:*

1. Hold mounting plate at desired location. With a pencil, mark the screw hole locations on the wall. These marks will be used to determine the location of your mounting hardware.
2. Remove mounting plate. Use a carpenter's level or measure up from the floor at each mark to ensure hook will be level.

### *Dry Wall Mounting*

1. Use a Phillips screwdriver to insert the wall anchors, slowly turn the anchors until they are threaded into the wall.
2. Align the mounting plate on the wall over the anchors, and insert screws with Phillips screwdriver until tight (*caution. do not over tighten the screw*).
3. Slide hook onto mounting plates.
4. Secure by tightening hex screw with Allen wrench.

### *Stud Mounting*

1. Hold mounting plate over the stud and with a Phillips screwdriver (or drill) insert screws into the mounting plates turning clockwise.
2. Slide mounting bracket onto mounting plate, secure by tightening small hex screw with Allen wrench.

### *Care Instructions:*

Wipe with a soft, dry cloth. To protect the finish, do not use household cleaners or abrasives.

