

# P O T T E R Y B A R N

## Farrah Nailhead Beaded Dot Mirror Mounting Instructions

This item includes two pairs of D-rings for mounting on a wall in either a portrait or landscape orientation. Only one D-ring pair is used.

**DO NOT USE CABLE TO HANG THIS MIRROR. THE MIRROR MUST HANG USING THE D-RINGS SUPPORTED DIRECTLY FROM THE PROVIDED HARDWARE!**

**Tools:** Level, Pencil, Tape Measure, Philips Screwdriver, Stud-Finder

The hardware included with this item is meant for drywall mounting only. If your walls are made from concrete, brick or plaster, please consult your local hardware store for assistance in selecting the appropriate hardware.

**Hardware: (2) Anchors and (2) Screws**

- 1) Use a tape measure to measure the distance between the D-rings (measure from the center of each). This is "Measurement (A)."
- 2) With the help of others, hold the mirror level against a wall at a desired mounting position and orientation so that the rear of the mirror faces towards you. Use a pencil to mark the wall immediately adjacent the mirror and in alignment with the two selected D-rings so that the two pencil marks and the two selected D-rings all horizontally align. Set the mirror aside.
- 3) Using a straightedge and a pencil, make a line on the wall connecting the two marks of Step (1). Use a level to make sure that the line is level. Adjust the line if necessary. Now use the pencil and the tape measure to make two "insertion" marks centered along this line so that the two marks are spaced a distance equal to Measurement (A). The mounting hardware will be installed at these two insertion marks.
- 4) The provided anchors cannot penetrate wood. Therefore we have to determine if either of the insertion marks happens to align with a wood stud. Use a stud-finder to determine this. If either does, use the screwdriver to secure a screw at the mark. Rotate the screw clockwise until the screw head is about 3/8 inch from the wall. Do not use the anchor at this mark.
- 5) For insertion marks that do not align with a stud, use a Phillips screwdriver to install an anchor into the wall. To do this, position the tip of the anchor against the wall at the mark and then firmly push the anchor into the wall as you rotate the anchor clockwise. The anchor is designed to drive itself into the wall as it is rotated. Continue rotating the anchor until the wide end becomes even with the surface of the wall.
- 6) Use the screwdriver to secure a screw into each installed anchor of Step (4). Rotate the screw clockwise until the screw head is about 3/8 inch from the wall.
- 7) With the help of another person, raise the mirror against the wall so that the selected D-rings are supported by the screw heads.

**Care Instructions:** To clean: wipe with a soft, dry cloth. Do not use abrasive or strong chemical household cleaners. A household glass cleaner may be used for the mirror surfaces – spray the cleaner on a clean cloth first and then use the cloth to clean the glass. Do not spray the cleaner directly onto the glass or frame surfaces.

Thank you for your purchase!