TTERYBA

Articulating Bath Sconce Assembly Instructions

Important Safety Instructions:

- These instructions are provided for your safety. It is very important that they are read carefully and completely before assembling
- We strongly recommend that a professional electrician install all direct wired fixtures.
- This fixture has been rated for up to (1) 60-watt maximum TYPE A standard bulb (not bulb). To avoid the risk of fire, do not exceed recommended wattage.

WARNING: This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

Parts Included:

- (1) Fixture base (A)
- (1) Mounting plate (B)
- (1) Adjustment key (C)
- (1) Threaded socket (D)
- (1) Glass shade (E)
- (1) Socket cover (F)
- (1) Threaded collar (G)

Hardware Included:

- (2) Mounting plate screws (G)
- (3) Base screws (H)

To Install You Will Need:

- Screwdriver
- Pliers
- **Electrical Tape**

Installation Instructions:

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Remove the mounting plate (B) from fixture base (A) by unscrewing the base screws (H).
- 3. Gently pull the wiring from the wall outlet box and allow the wires to hang. Thread the wires through the center hole in the mounting plate.
- 4. Affix the mounting plate to the wall outlet box with the mounting plate screws provided (G).
- 5. Wrap the ground fixture wire (green) to around the ground screw found on the mounting plate or connect it to the ground wire found in the wall outlet box (usually green or copper in color). If attaching to ground wire in outlet box, fasten together with a plastic wire connector and tightly wrap the connection with electrical tape to seal the connector. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
- 6. Connect neutral (white) fixture wire to the neutral (usually white) outlet wire. Fasten together with a plastic wire connector and tightly wrap the wire connector with electrical tape.
- 7. Repeat this procedure with the hot (black) wire. Always make sure that no wire strands are left outside the connectors. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 8. Attach the fixture base (A) to the affixed mounting plate (B) by aligning the holes and inserting the base screws (H). Tighten with screwdriver.
- 9. Unscrew the threaded collar (G) from the threaded socket (D) and take out the socket cover (F).
- 10. Attach the glass shade (E) over threaded socket (D) until thread of socket protrudes from the opening at bottom of the shade.
- 11. Secure shade (E) by re-attaching socket cover (F) and threaded collar (G) to the thread of socket. Tighten by turning clockwise.
- 12. Insert bulb (not included).
- 13. Restore power and test fixture. Installation is complete.

To adjust lampshade:

- Loosen the adjustment key (C) by turning counter-clockwise
- Adjust socket and shade to desired position and secure by turning the adjustment key (C) clockwise.

Care Instructions:

Lamp base: Wipe clean using only a dry cloth. Avoid the use of all detergents and chemicals. Glass shade: Remove and hand wash thoroughly. Do not use cleaners or abrasives.

> thank you for your purchase stores | catalog | www.potterybarn.com

