



P O T T E R Y B A R N

MONOGRAMMABLE HOOK S2 ATQ SLV

Mounting instructions

Note:

This mounting hardware is meant for dry wall/stud mounting only. If walls are concrete, brick or plaster, please consult your local hardware store for assistance. For safety and ease of mounting, installation is recommended using two people. Do not use or attach wire for hanging the mirror, it is meant to hang from the affixed d-rings on the back.

Tools needed

Level, Tape Measure, Stud Finder, #2 Phillips screwdriver, Pencil

Hardware Included:

- (1) Metal Screws
- (1) Dry Wall Anchors (for dry wall only)
- *For stud mounting the anchors are not required, use only the screws.*

Mounting Instructions:

1. Determine your desired hanging location. Measure the distance between the d-rings on the back of the Product, making sure the measurements are taken from the centers of both d-rings.
2. Record this measurement on the wall with a pencil. Use a carpenter's level and a tape measure to ensure a level installation.
3. Stud mounting is always best, so try to position the d-rings over studs if possible. Use a stud finder to locate a stud in desired location. If any of the d-rings align with stud, use provided metal mounting screws. If there is no stud, the wall anchors/metal screws are both required.

Dry Wall Mounting

1. Use a Phillips screwdriver to insert the wall anchors. Do not "push" or drive the anchors into the wall, it is designed to bore into the wall like a drill bit. Slowly turn the anchors clockwise while applying pressure until the flange just touches the wall.
2. Insert the metal screw into the wall anchor turning clockwise leaving approximately ½" between the back of the screw head and the wall.
3. Align the d-rings over the screw heads and slide the mirror down until the tops of the d-rings rest on the screws. Tighten or loosen screws as needed to fit the mirror snugly against the wall.

Stud Mounting

1. With a Phillips screwdriver (or drill) insert metal screws into the stud clockwise until tight.
2. Align the d-rings over screw heads and slide the mirror down until the tops of the d-rings rest on the screws.

thank you for your purchase