

P O T T E R Y B A R N

WILLIAM WALL STORAGE

Mounting instructions

Tools Required: Level, Pencil, Phillips Screwdriver,
Stud-Finder,

Hardware: TWO Anchors
TWO Screw Hooks

The hardware included with this item is meant for drywall or stud mounting only. If your walls are made from concrete, brick or plaster, please consult your local hardware store for assistance in selecting the appropriate hardware.

This wall-hanging system includes separate units that are designed to hang one from another by engaging the pre-installed brackets and loops. The uppermost unit hangs from screw hooks that are secured to the wall. The screw hooks can be secured to drywall using the provided anchors, or directly into wall studs (no anchors) in cases where a stud aligns with one of the marks. The units can be moved around to form any desired combination of functions. However, we do strongly recommend that no more than 3 units be arranged in any one column.

Mounting Instructions:

- 1) With the help of at least one friend, hold upright one of the units against the wall in a desired mounting location. Place a level on top of the unit to verify that the unit is level and then use a pencil to mark the wall through each of the two pre-mounted loops located on the top of the unit. Mark the wall at the 12 o'clock position of each loop. Set the unit aside. The remaining two marks on the wall are the locations for the mounting hardware.
- 2) Use the level to ensure that the two marks are level with respect to each other. Adjust the marks as necessary.
- 3) The anchors provided with this product cannot penetrate wood studs. Therefore we have to find out if either of the two marks of Step (1) happen to align with a wall stud (use a stud-finder to determine this). If a mark does align, use your hand to rotate a screw hook directly into the wall. You may have to tap the end of the hook GENTLY with a hammer to help start the screw threads into the sheetrock. Alternatively you may use a power drill to create a pilot hole at the marks. The size of the drill bit should be about 7/64 in. Either way, rotate the screw hook using your hands so that its threads fully engage the wall.
- 4) For each mark that does not align with a stud, use a screwdriver to install an anchor into the wall at the mark. Place the tip of an anchor at the mark and use the screwdriver to both rotate the anchor (clockwise) and gently push it into the wall. The anchor will drive itself into the wall like a screw. Continue rotating the anchor until its wide flange is even with the wall surface. Do not over-tighten.
- 5) Use your hands to secure a screw hook into each installed anchor. Rotate the screw hook clockwise until tight.
- 6) Carefully hang the uppermost unit onto the installed hooks. Once secured, additional units may be attached to this first one by engaging the upper loops of a newly revised version with the lower brackets of the mounted top unit. We strongly recommend that only TWO units be attached to a fix-one.

Care Instructions:

Dust often with a soft, dry cloth
Avoid using strong chemical or abrasive cleaners.

Thank you for your purchase