

P O T T E R Y B A R N

Vintage Trifold Mirror

Mounting Instructions

Hardware Included:

- (3) Screws
- (3) Drywall Anchors

Tools Needed:

- Screwdriver
- Pencil
- Level
- Stud-Finder

The hardware included with this item is meant for Drywall and stud mount only. If your wall is made from another material such as concrete or plaster, please consult your local hardware store for assistance in selecting the correct hardware.

Mounting Instructions:

- 1) With the help of another person, hold the trifold mirror item upright against a wall at a desired location. Use a bubble level to level the item and then use a pencil to mark the wall through the two holes of the two tabs located at the top of the mirror and the additional hole of a third tab centrally located along the bottom edge of the mirror. Set the mirror aside.
- 2) Use a stud finder to determine if any of the three marks of Step (1) aligns with a wall stud. If so, use only a provided screw at the stud-aligned mark when instructed below.
- 3) For each mark that does not align with a stud, install a provided anchor by positioning the anchor tip at the mark. Use the screwdriver to rotate the anchor clockwise while you push the anchor into the wall. The anchor will drive itself into the wall as it is rotated. Continue to rotate the anchor until the wide end is even with the wall surface.
- 4) With the help of another person hold the trifold mirror against the wall so that the three holes align with either installed anchors or a stud-aligned mark. Use the screwdriver to secure a screw through each through-hole and into the installed anchors or directly through the wall and into a stud. Rotate each screw clockwise until each is tight. We recommend that you first secure a screw in one of the two upper holes that aligns with an installed anchor first. By doing this, the weight of the mirror can be supported early allowing the other screws to be more easily secured (give your helper a break).
- 5) The trifold mirror is now ready to use.

Care Instructions:

Wipe with a soft, dry cloth.
Do not use strong chemical or abrasive cleaners.

