


POTTERY BARN



ABBOTT RECT. DINING TABLE WITH CEMENT TOP

Important Safety Instructions:


- Please read all instructions carefully before assembling.
- For your safety and convenience, assembly by four adults is strongly recommended.
- Keep instructions for future use.
- Use only hardware supplied by vendor to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item.

Pre-assembly:


- Remove all parts and hardware from the box and lay them out on a clear carpeted or scratch-free work surface, to avoid damaging parts during assembly. The shipping box provides an ideal work surface.
- Save all packing materials until assembly is complete to avoid the accidental discarding of smaller parts or hardware.
- Use the parts and hardware list below to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- The use of power tools is not recommended. Power tools can damage hardware and split wood.

Parts included:


(A)	Cement Top	1 pc
(B)	X Bases	2 pcs
(C)	Mounting Panels	2 pcs
(D)	Stretcher	1 pc
(E)	Decorative Wedges	2 pcs




(A)



(B)



(C)




(D)



(E)

Hardware Included:

(F) Long Bolts	(G) Short Bolts	(H) Flat Washers	(I) Spring Washers	(J) Temporary Alignment Screws
				
Ø8mm x L 110 mm	Ø8mm x L50 mm	Ø8mm x 22mm	Ø8mm x 12mm	Ø8mm x L70mm
2 pcs	16 pcs	18 pcs	18 pcs	2 pcs

Tool Required:

(K) – Allen Key (included)




(1pc)

Assembly Instruction Steps:

1. Carefully put down X Base (B) on a carpeted or scratch-free surface.
2. Attach Mounting panel (C) to X Base (B) by using 2 Short Bolts (G), 2 Spring Washers (I) and 2 Flat Washers (H). Tighten with Allen Key (K). (See Fig. 1).
3. Repeat step 2 to attach the remaining Mounting panel (C) to the other X Base (B).


Fig. 1

Allen key




4. Attach the Stretcher (D) into the legs. Make sure the dowels of Stretcher are aligned with the holes of both X Bases. (See Fig. 2)

Fig. 2




5. Insert the dowels into the holes, and attach Stretcher to X Bases by using 2 Long Bolts (F), 2 Spring Washers (I) and 2 Flat Washers (H). Tighten with Allen Key (K), from the outside. (See Fig. 3)

Fig. 3



6. Carefully lay Top (**A**) upside down on a scratch free surface. Insert 2 **Temporary** Alignment Screws (**J**) into the threaded holes on Top (**A**). Attention: The 2 **Temporary** Alignment Screws (**J**) should be inserted into 2 diagonally opposed threaded holes. (See **Fig.4**) The purpose of these **Temporary** Alignment Screws is to properly position the X Bases for more easily inserting the rest of the bolts.

Fig. 4




7. With X Bases upright, place Top (**A**) upright on assembled base by aligning the two **Temporary** Alignment Screws (**J**) to holes on Mounting Panels (**C**). (See **Fig. 5**)

Fig. 5




8. Attach Top **(A)** to assembled base by using 10 Short Bolts **(G)**, 10 Spring Washers **(I)** and 10 Flat Washers **(H)**. Then, remove the 2 **Temporary** Alignment Screws, and insert the final 2 Short Bolts **(G)**, 2 Spring Washers **(I)** and 2 Flat Washers **(H)**. Tighten with Allen Key **(K)**. (See **Fig. 6**)

Fig. 6



9. Attach Decorative Wedges **(E)** by sliding them down tightly on two sides of X Bases. (See **Fig. 7**)

Fig. 7




10. Assembly is complete.

Adjusting Levelers:

Due to an uneven floor the Table may not sit level causing it to wobble. If the Table wobbles, determine which corner does not touch the ground correctly. With two people follow these steps:

1. Carefully lift the table slightly to provide access to the levelers attached to the bottom of the legs.
2. Turn the levelers until adequate contact is made with the floor. Gently set down the Table and check stability.
3. Repeat steps until Table sits firmly on the ground.



Care Instructions:

- It is important to store wood and cement furniture INDOORS out of season. Make certain that the furniture is completely dry before storage.
- Cover furniture with outdoor covers (sold separately) when left outside during inclement weather or when not in use.
- Wipe spills with a clean dry cloth. Do not use chemicals or abrasives for cleaning!
- For the Wood base, periodically apply a high quality outdoor furniture oil to darken the finish and add protection.
- For the cement top, periodically apply a light coating of any quality furniture wax.
- **TAKE NOTE: THE BOLTS MAY SLIGHTLY LOOSEN OVER TIME. IF YOUR FURNITURE FEELS "WOBBLY" OR LOOSE, PLEASE RE-TIGHTEN BOLTS.**

Thank you for your purchase.
stores | catalog | www.potterybarn.com