

NO.	DESCRIPTION	Q'TY	NO.	DESCRIPTION	Q'TY
G1	SPOUT	1	G18	BODY LOCK NUT	2
G2	POP-UP ROD	1	G19	HOT CARTRIDGE	1
G3	SPO.BASE O-RING	1	G20	COLD CARTRIDGE	1
G4	SPO. FIT WASHER	1	G21	FAUCET BODY	2
G5	SPO. LOCK NUT	1	G22	CONNECT HOSE	2
G6	TEFLON WASHER	1	G23	CONE WASHER	2
G7	CONNECT TEE	1	G24	TUBE LOCK NUT	2
G8	CON. TEE O-RING	1	G25	DRAIN FACE	1
G9	BRASS WASHER	1	G26	POP-UP FLANGE	1
G10	CON. TEE NUT	1	G27	DRAIN BODY	1
G11	H. HANDLE CAP	1	G28	BALL WASHER	2
G12	C. HANDLE CAP	2	G29	PIVOT ROD	1
G13	HANDLE SCREW	2	G30	LOCK NUT	1
G14	CROSS HANDLE	2	G31	SPRING CLIP	1
G15	HANDLE BASE	2	G32	ROD STRAP	1
G16	RUBBER WASHER	2	G33	SCREW	1
G17	PLASTIC WASHER	2			

Pre-assembly:

- Before beginning installation, use the parts list above to identify each of the components included.

Care: Clean faucet with soapy water and a soft cloth or sponge. Rinse thoroughly with water. Wipe dry. Drying immediately after use helps prevent lime deposits from forming. To protect the finish, do not use abrasive agents or harsh cleansers. If using a cleaning agent, it is best to first test on a small inconspicuous spot before applying solution to entire faucet.

thank you for your purchase
stores | catalog | www.potterybarn.com

POTTERY BARN
Gooseneck Widespread Sink Faucet
Installation Instructions
Model # FS-805EX

Professional Installation Required

Important Safety Instructions:

- Please read all instructions carefully and completely before beginning installation.
- Remove all parts and hardware from the box and lay out on a clear workspace, along with any plastic protective packaging.
- Do not dispose of any packaging or contents until assembly is complete to avoid accidentally discarding small parts or hardware.