

P O T T E R Y B A R N

Sussex Double Hook

Assembly Instructions

Note:

For safe mounting, it is essential to use the proper hardware for your wall type. Be sure to consult your local hardware store to determine the hardware needed for your wall type (plaster, drywall, concrete, etc.). Mount to wood studs whenever possible.

The maximum weight capacity is 20 lbs (9.1 kgs). Do not exceed the load capacity.

Parts Included:

- (2) Screws
- (6) Wall anchors
- (1) Double hook

Mounting Instructions:

1. Hold fixture at desired location. With a pencil, mark on wall the two screw holes. These marks will be used to determine the location of your mounting hardware.
2. Remove fixture. Use a carpenter's level or measure up from the floor at each mark to ensure hook will be level.
3. Mount fixture using hardware provided or proper hardware for your wall type.

Care Instructions:

Wipe with a soft, dry cloth. To protect the finish, do not apply any household cleaners or abrasives.

thank you for your purchase

stores | catalog | www.potterybarn.com