

# P O T T E R Y B A R N

## Studio Wall Easel System

### mounting instructions

Note: For safe mounting, it is essential to use the correct hardware for your wall type (drywall, concrete, etc.) Be sure the display rod is securely mounted and can support the weight of your artwork, picture, etc. When in doubt, contact your local hardware store to determine the hardware needed. Mount to wood studs whenever possible. Use of a carpenter's level is recommended to ensure proper installation.

#### Hardware included:

- (2) Metal Screws
- (2) Dry Wall Anchors (for dry wall only)

For stud mounting the anchors are not required, use only the screws.

#### Mounting instructions:


Note: Stud mounting is always best, so try to position the display rod over studs if possible.

#### Stud Mounting

1. Hold the display bar at the desired location on the wall.
2. With a pencil, mark on the wall the inside of each screw hole of display bar.
3. These marks will be used to determine the location of your mounting hardware.
4. Use a stud finder to locate a stud in desired location.
5. If any of the points of the display rod align with stud, use provided metal mounting screws.
6. With a Phillips screwdriver (or drill) insert metal screws into the stud clockwise until tight.
7. Place the display rod on wall.

#### Dry Wall Mounting

1. Use a Phillips screwdriver to insert the wall anchors.
2. Do not "push" or drive the anchors into the wall, it is designed to bore into the wall like a drill bit.
3. Slowly turn the anchors clockwise while applying pressure until the flange just touches the wall.
4. Align the display rod over the anchors.
5. Insert the metal screw into the wall anchor turning clockwise leaving approximately 1/2" between the back of the screw head and the wall.
6. Place the display rod on wall.



#### Care instructions:

To clean wipe with a soft, dry cloth.

thank you for your purchase  
stores / catalog / [www.potterybarn.com](http://www.potterybarn.com)