

# P O T T E R Y B A R N


## Knob Installation Instruction

Note: There is a set of polished nickel knobs pre-attached to the product you have purchased. To replace them with a set of the enclosed knobs, please follow the instructions below.

### Enclosed:


- (1) Set of chrome knobs
- (1) Set of satin nickel knobs

### Tool needed:



Phillips Head Screwdriver (not included)

1. Using a Phillips Head Screwdriver, release the pre-attached Knob Bolts on the inside of the door, by turning counter-clockwise. This detaches the pre-attached knobs.
2. To replace with the other set of knobs use the Phillips Head Screwdriver and insert the Knob Bolts into the knobs from inside of the door and turn clockwise.



thank you for your purchase  
stores | catalog | [www.potterybarn.com](http://www.potterybarn.com)