

# POTTERY BARN

## DARCY FOUNTAIN

### ASSEMBLY INSTRUCTIONS

#### CAUTION:

This Pump Has Been Evaluated for Use With Water Only.

#### Important Safety Instructions:

- These instructions are provided for your safety. It is very important that you read carefully before beginning the assembly and installation of this water fixture.
- This product must be installed in accordance with the applicable installations codes by the person familiar with the constructions and operation of the product.
- The water fixture is meant for outdoor use.
- For your safety, it is strongly recommended that two people install the water fixture.
- Save these instructions.

#### WARNING:


- This pump is supplied with a grounding conductor and grounding-type attachment plug. To reduce the risk of electric shock, be certain that it is connected only to a properly grounded, grounding-type receptacle.
- To reduce risk of electrical shock or personal injury. Do not plug the submersible pump without water.

#### PARTS INCLUDED:


- (A) BASE (1)
- (B) BASIN (1)
- (C) TOP TIER (1)
- (D) ALUMINUM TUBE (1)
- (E) FLEXIBLE HOSE (1)
- (F) PVC PIPE (1)

#### ACCESORIES INCLUDED:


- (G) SUBMERSIBLE WATER PUMP (1)




## Assembly Instructions:



1. Put the base of the fountain (A) and place the basin of the fountain (B) at the top part of the base of the fountain (A), twist clockwise to lock.



2. Put the submersible pump (G) inside the basin (B) of the fountain. Then insert its electrical wire into the hole of the pipe (F) that is on the inner part of the basin (B) of the fountain. Thread the electrical wire through the body of



3. Put the top tier (C) of the fountain and connect the flexible hose (E) to the spout of the submersible pump (G). Make sure the flexible base (E) is connected tightly to the submersible pump (G) then place the top tier (C) on the basin (B) of the fountain.



4. Put 4 litres of water inside the basin (B) of the fountain then Plug the male plug into the outlet.

To replace the submersible pump, please follow these steps:

1. Unplug the water pump to power supply.
2. Remove any existing water on the basin of the fountain.
3. Lift the top tier (C) and detach the flexible hose from the submersible pump.
4. Pull out the wire power cord of submersible pump from the basin of the fountain.
5. Insert new submersible water pump into the basin, then connect the flexible hose into the water pump.

Care Instructions:

- Handle with extra care.
- Wipe with clean wet rag.

Thank you for your purchase  
Store | Catalogue | [www.potterybarn.com](http://www.potterybarn.com)  
USA 1.888.779.5176