POTTERYBARN

Articulating Sconce Assembly Instructions

Important Safety Instructions:

- These instructions are provided for your safety. It is very important that they are read carefully and completely before assembling fixture.
- We strongly recommend that a professional electrician install all direct wired fixtures.

To Install You Will Need:

Electrical Tape

Screwdriver

Pliers

• This fixture has been rated for up to (1) 60-watt maximum TYPE A standard bulb (not bulb). To avoid the risk of fire, do not exceed recommended wattage.

WARNING: This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

Parts Included:

- (1) Fixture base (A)
- (1) Mounting plate (B)
- (1) Threaded socket (C)
- (1) Glass shade (D)
- (1) Threaded collar (E)
- (2) Adjustment keys (F)

Hardware Included:

- (2) Mounting plate screws (a)
- (3) Set screws (b)
- (1) Washer (c)

Installation Instructions:

- SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Remove the mounting plate (B) from fixture base (A) by unscrewing the set screws (b).
- 3. Gently pull the wiring from the wall outlet box and allow the wires to hang. Thread the wires through the center hole in the mounting plate.
- 4. Affix the mounting plate to the wall outlet box with the mounting plate screws (a) provided.
- 5. Wrap the ground fixture wire (green) to around the ground screw found on the mounting plate or connect it to the ground wire found in the wall outlet box (usually green or yellow). If attaching to ground wire in outlet box, fasten together with a plastic wire connector and tightly wrap the connection with electrical tape to seal the connector. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
- 6. Connect neutral (white) fixture wire to the neutral (usually white) outlet wire. Fasten together with a plastic wire connector and tightly wrap the wire connector with electrical tape.
- 7. Repeat this procedure with the hot (black) wire. Always make sure that no wire strands are left outside the connectors. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
- 8. Attach the fixture base (A) to the affixed mounting plate (B) by aligning the holes and inserting the set screws (b). Tighten with screwdriver.
- 9. Remove the threaded collar (E) and washer (c) from the threaded socket (C).
- 10. Attach the glass shade (D) over threaded socket (C) until thread of socket protrudes from the opening at bottom of the shade.
- 11. Secure shade (D) by re-attaching washer (c) and threaded collar (E) to the thread of socket. Tighten by turning clockwise.
- 12. Insert bulb (not included).
- 13. Restore power and test fixture. Installation is complete.

To Adjust Base Height:

- · Loosen the adjustment key (C) by turning counter-clockwise. Select the desired height.
- Secure by turning adjustment key clockwise to tighten.

Care Instructions:

Lamp base: Wipe clean using only a dry cloth. Avoid the use of all detergents and chemicals. Glass shade: Remove and hand wash thoroughly. Do not use cleaners or abrasives.

thank you for your purchase stores | catalog | www.potterybarn.com

