

# POTTERY BARN

## charlotte armoire

### Pre-assembly:


- Please read all instructions carefully before beginning assembly.
- Save all packing materials until the armoire is fully assembled to avoid accidentally discarding any small parts or hardware. Use the parts and hardware lists to identify and separate each of the components included.
- Use caution if using power tools to aid in assembly. Tools can split wood or strip hardware when not used properly.

**Note:** This armoire is intended for use with tube TV's with a maximum screen size of 32 inches and/or weight of 135 lbs.

### Parts Included:



(8) Shelf Pins – A




(2) Shelves – B



(1) Clothes rod– C

### Assembly Instructions:



1. Put the shelf pins into the pre-drilled holes.
2. Place the shelves onto the pins.
3. Place the clothes rod onto the rod holder attached to the sides of the armoire.

Care: Dust often with a soft, dry cloth.

thank you for your purchase  
stores | catalog | [www.potterybarn.com](http://www.potterybarn.com)