

French Wire Hamper

1. Place the folded laundry basket on the floor with the wheels on top.
2. Raise each of the legs and pull up on the square wire leg support. Turn the laundry basket over and press down on the square leg support to lock it in place.
3. Pull up on the collapsible wire section of the basket
4. There is a center round wire ring that has 4 small clips attached. Pull this ring upward and clip them to the sides of the basket. This will lock the basket in the open position

