



# P O T T E R Y B A R N

## 2 foot holman ledge mounting instructions

**Note: This hanging system is meant for dry wall/stud mounting only.** If walls are concrete, brick or plaster, please consult your local hardware store for assistance. For safety and ease of mounting, installation is recommended using two people.


**Maximum weight capacity for 2-foot ledge is 35 lbs**

### Tools needed:

- Electronic stud Finder, #2 Phillips screwdriver, Drill with #2 Phillips bit, Pencil

### Hardware Included:

- (1) Wall Mounting Bracket with Bubble Level
  - (2) Stud Mounting Screws (1.5" screws with sharp tip)
  - (2) Toggle Anchors
  - (2) Toggle Screws
- (The Toggle Anchors and Toggle Screws are meant for dry wall only)




Stud Mounting Screw

Toggle Screw

Toggle Anchor

### Mounting Instructions:

1. Determine the desired placement on the wall for the product. Within the desired mounting location, locate the wall studs using the electronic stud finder and mark stud locations using the pencil. (Note: It is best to mount the bracket to at least (1) stud, using the illustrative graph shown below for reference.)
2. Determine which wall mount bracket hole or holes on the wall that will be centered on a stud. The hole positions that are centered over studs will use the Stud Mounting Screws for mounting the bracket.
3. Insert the included bubble level into the bubble level track, as close to the center of the wall mount bracket as possible.
4. Place the wall mount bracket at the desired location on wall and confirm that the bracket is level.
5. With the pencil, mark the mounting screw hole locations on the wall with the pencil.
6. Remove the wall mount bracket and set aside.



### Stud Mounting

1. Install the wall mount bracket onto the wall using the Stud Mounting Screw at one of the stud locations first, using the #2 Phillips screwdriver or the drill with a #2 Phillips bit. Insert the first Stud Mounting Screw through the hole in the wall mount bracket and tighten clockwise. Leave the Stud Mounting Screw slightly loose so that the wall mount bracket can still be rotated and the wall mount bracket area on the wall is exposed for installing the dry wall toggle anchor(s).

### Dry Wall Mounting

1. Use the #2 Phillips screwdriver to install the toggle anchor(s).

**IMPORTANT NOTE: DO NOT USE THE DRILL TO INSTALL THE TOGGLE ANCHORS.** Also do not force or "pound" the anchor into the wall. The toggle anchor is designed to cleanly cut and bore itself into the wall somewhat like a drill bit.

2. Slowly turn the anchor clockwise while applying even pressure until the flange just touches the wall. If the anchor position is close to a stud (1/2" or less), keep turning clockwise until one of the arrows on the flange is pointing to the 12 o'clock position.
3. Insert the toggle screw into the toggle anchor turning clockwise. At this point, you will feel a slight resistance. This is the point where the toggle anchor screw is engaging the pivoting portion of the anchor. Continue turning the screw clockwise until the screw head touches the flange. Tighten the toggle anchor screw until it becomes difficult to turn. At this point the internal pivot will have engaged the backside of the dry wall. Remove the toggle anchor screw, turning counter-clockwise.
4. Align the wall mount bracket on the wall over the toggle anchor(s), and re-insert toggle anchor screw(s) with the #2 Phillips screwdriver until tight.

### Hanging the Product:

1. On the back of your product is an affixed product-mounting bracket.
2. Carefully position the product-mounting bracket over the wall mount bracket, insuring that the two brackets are aligned.
3. Press down firmly to engage the two brackets.
4. Your product is ready for use.

Thank You for Your Purchase