

Vintage Pedestal Console Installation Instructions

Materials included for installation:



- Sink Basin
- One Pedestal
- Two Lag Bolts
- Two Rubber Washers
- Two Metal Washers

Tools and Materials Required for Installation:

- Caulking
- 1/8" drill bit
- Socket wrench
- Pencil
- Level
- Tape measure
- Construction Adhesive (optional)

This pedestal sink is meant to be secured to a wall using two lag bolts (included) and **MUST** always be supported by the pedestal. It is critical that the wall framing be properly reinforced by securing a support block of wood using a 2in by 10in wood member between two nearby studs. This support block is positioned to receive the lag bolts that support the sink. Of course, all the required plumbing must be properly installed, awaiting connection.

Cut-away showing required wall construction




Assembly Instructions:

The underside of the sink basin includes molding that is sized to receive the top end of the pedestal.

Mounting Instructions:

- With the help of two other people hold the sink upright against the wall and move the pedestal under the basin. Set the basin on top of the pedestal.
- With the pedestal in place, lean the back of the basin against the wall and measure up from the floor to the top of the basin. This measurement should be 35 1/8" inches. Place a level on the top of the basin to ensure that it is level and adjust the basin as necessary.
- Once all is true and at the correct height, mark the wall through the two holes located in the back of the basin. Carefully set the basin and pedestal aside.
- Using a power drill and a 1/8 inch drill bit, drill a pilot hole into the wall at each mark.
- Again with the help of two other people, return the sink basin and the pedestal to the mounting position against the wall. Recheck the level and height of the basin and align the mounting holes of the back of the basin with the pilot holes in the wall.

- F) Secure the basin to the wall by inserting a lag bolt first through a metal washer, then a rubber washer and then through each mounting hole of the sink. Tighten each bolt using an appropriate wrench from under the sink. **DO NOT OVER-TIGHTEN THESE BOLTS - DOING SO CAN EASILY CRACK THE BASIN!**



- G) Apply a bead of caulking between the back of the basin and the wall
- I) Install the faucet and drain assembly per manufacturer's instructions and connect the drain plumbing and water feed lines.

Installation Complete.